

DS4001(94001) Installation Instructions

- 1) Figure your bracket height, keeping in mind the drapery should be at least 1/2" off the floor.
- 2) End brackets should be installed within 6" of track ends. Especially on the pull cord side. We suggest the next bracket to be within 24" of the end brackets. All remaining brackets can have a spacing of 24-48" apart, depending on the drapery weight.
- 3) Insert track into brackets. The front edge of the bracket will tuck into the front lip on the track, then push the back side of the track up against the bracket and swivel the loosened silver cam so that it catches under the back track lip. Then tighten the cam.
- 4) Install cord tension pulley near or onto the baseboard. Pull up on the top of the pulley to expose a small hole and insert a nail or small wire ect into the hole. Then take the slack out of the cord by pulling on the knot behind the master that is closest to the cord side. Once correct tension is made, tie a new double knot close to the master. Then release the object that was inserted into the tension pulley. You should now have correct tension on the cord and can cut off the excess cord.
- 5) If installing a child safe cord tension device, please see the separate instructions for those on our website.

