

Multidraw Samples

For multidraw rods to work:

- 1) All windows have to be the same size, whether there are 2, 3 or 4 windows.
- 2) To keep the drapery opening in the center of your windows, you can only extend the rod to the far left or right by half of the space in between your windows.

